

VAPOR-LOGIC EXTERNAL CONTROL CONNECTIONS DIAGRAM





NOTES:

- CHANGING CONTROL INPUT SIGNAL MAY REQUIRE WIRING CHANGE AND PROGRAM CHANGE. REFER TO VAPOR-LOGIC INSTALLATION AND OPERATION MANUAL (IOM), KEYPAD INPUT SELECTION SUB-MENU.
- FOR ALL CONTROL DEVICES, EXCEPT WATER LEVEL CONTROLS/PROBE USE:

 18 AWG/1.5 mm² PLENUM RATED 2—WIRE SHIELDED CABLE.
- THIS PRODUCT WAS FACTORY TESTED FOR PROPER OPERATION. FAULTY HANDLING OR WIRING IS NOT COVERED UNDER DriSteem'S WARRANTY.
- 4. REMOVE POWER BEFORE WIRING CONNECTIONS.
- $\stackrel{\frown}{\otimes}$ refer to transmitter install instructions.



CONTROL CIRCUIT
WIRING
FIELD WIRING
OPTIONAL FACTORY
OPTIONAL FIELD

