


VAPORMIST® EVAPORATIVE HUMIDIFIER FACTORY WIRING DIAGRAM WITH VAPOR-LOGIC

DATE	REV	RECORD	DR
5/15	A	E.C.# 6396	JK
4/17	B	E.C.# 6551	JK
4/21	C	E.C.# 6969	JK




- NOTES:
- FOR THREE PHASE SYSTEM, THE THREE PHASE LOAD IS USED AND THIS WIRE IS FACTORY INSTALLED.
 - WATER LEVEL PROBE GROUND MUST BE CONNECTED TO TANK FOR PROPER HUMIDIFIER OPERATION.
 - ONLY USED ON THREE PHASE POWER.
 - REFER TO VM ELECTRICAL DATA SHEET.

POWER WIRING
CONTROL CIRCUIT WIRING
FIELD WIRING
OPTIONAL FACTORY
OPTIONAL FIELD

LEGEND

- | | | | |
|---|-----------------|---|-------------------|
| K | RELAY/CONTACTOR | Y | SOLENOID |
| T | TRANSFORMER | N | SENSOR |
| Q | CIRCUIT BREAKER | J | JUMPER |
| S | SWITCH | E | WATER PROBE |
| H | HEATER | M | MOTOR/FAN |
| F | FUSE | R | SOLID STATE RELAY |
- BREAK TO EXTERNAL CONNECTIONS DIAGRAM



		VM, STANDARD WATER, SSR WIRING DIAGRAM	
		MATERIAL:	
SCALE:	P/N	VM-VL-36	
DRAWN BY: JK	DATE: 5/18/15		