



VAPORMIST® EVAPORATIVE HUMIDIFIER FACTORY WIRING DIAGRAM WITH VAPOR-LOGIC

DATE	REV	RECORD	DR
5/15	A	E.C.# 6396	JK
4/17	B	E.C.# 6551	JK



NOTES:

1. WATER LEVEL PROBE GROUND MUST BE CONNECTED TO TANK FOR PROPER HUMIDIFIER OPERATION.

2. REFER TO VM ELECTRICAL DATA SHEET.

POWER WIRING

CONTROL CIRCUIT WIRING

FIELD WIRING

OPTIONAL FACTORY

OPTIONAL FIELD

LEGEND

- | | | | |
|---|-----------------|---|-------------------|
| K | RELAY/CONTACTOR | Y | SOLENOID |
| T | TRANSFORMER | N | SENSOR |
| Q | CIRCUIT BREAKER | J | JUMPER |
| S | SWITCH | E | WATER PROBE |
| H | HEATER | M | MOTOR/FAN |
| F | FUSE | R | SOLID STATE RELAY |

BREAK TO EXTERNAL CONNECTIONS DIAGRAM

		VM, STANDARD WATER, SSR, SDU WIRING DIAGRAM 120 VOLT	
		MAT'L:	P/N
SCALE:	DATE: 5/18/15	VM-VL-38	
DRAWN BY: JK			