


VAPORMIST® EVAPORATIVE HUMIDIFIER FACTORY WIRING DIAGRAM WITH VAPOR-LOGIC

DATE	REV	RECORD	DR
11/13	A	E.C.# 6157	JK
1/14	B	E.C.# 6172	JK



NOTES:

1. FOR THREE PHASE SYSTEM, THE THREE PHASE LOAD IS USED AND THIS WIRE IS FACTORY INSTALLED.

2. WATER LEVEL PROBE GROUND MUST BE CONNECTED TO TANK FOR PROPER HUMIDIFIER OPERATION.

3. ONLY USED ON THREE PHASE POWER.


4. REFER TO VM ELECTRICAL DATA SHEET.

POWER WIRING
CONTROL CIRCUIT WIRING
FIELD WIRING
OPTIONAL FACTORY
OPTIONAL FIELD

LEGEND

K	RELAY/CONTACTOR	Y	SOLENOID
T	TRANSFORMER	N	SENSOR
Q	CIRCUIT BREAKER	J	JUMPER
S	SWITCH	E	WATER PROBE
H	HEATER	M	MOTOR/FAN
F	FUSE	R	SOLID STATE RELAY

BREAK TO EXTERNAL CONNECTIONS DIAGRAM



		VM, STANDARD WATER, SSR WIRING DIAGRAM	
		SCALE: 11/5/13	P/N VM-VL5-36
DRAWN BY: KROG		DATE: 11/5/13	