

A large, white iceberg floats in a dark blue ocean under a vast, blue sky with wispy clouds. The iceberg's surface is uneven and jagged, with a prominent peak on the right side. The water around the iceberg shows some ripples and a slight wake.

WATER FUNDAMENTALS HANDBOOK

First Edition

Water Fundamentals Handbook

First Edition

Steve Felber

Copyright © 2017 by DRI-STEEM Corporation

All rights reserved. No part of this publication may be reproduced or transmitted, in any form or any means, without the written permission of the company.

*Printed and bound in the United States of America.
First printing September 2017.*

*DRI-STEEM Corporation
14949 Technology Drive
Eden Prairie, MN 55344
800-328-4447 or 952-949-2415
952-229-3200 (fax)*

FORWARD

The focus of this handbook is water. What is it about water that gives it such unique properties? How do those properties relate to DriSteem products? All DriSteem products involve water processing in some way, whether creating steam for humidification, passing water over media, injecting small droplets of water into spaces for cooling and humidification, or removing dissolved substances from water to purify or soften it. Since water is such an integral part of all DriSteem systems, it seems appropriate to dig a little deeper into the impacts of water as it relates to the products DriSteem offers.

Since 1965, DriSteem's focus has been on developing competitive products that meet the needs of its customer base. In order for DriSteem to continue enhancing customer satisfaction by offering maximum performance and functionality in its products, a deeper understanding of water and how it affects products is essential to the company.

The reason for this handbook is to help the reader better appreciate the uniqueness of water and how such tiny molecules can affect the products we design and build every day to satisfy the needs of the many customers we serve.

Table of contents

FORWARD	v
SECTION I: WATER BASICS	1
Unique characteristics of water	2
Hydrogen bonds	2
Bent structure	3
Attraction to other substances	4
Implications of dissolved solids	5
SECTION II: WATER HARDNESS	7
Hard water	8
Hard water scale	9
Alkalinity	10
Bicarbonate alkalinity and scale	10
Approaches to solving the hard water problem	10
Softened water	10
Reverse osmosis (RO) water	12
Deionized (DI) water	13
Other water treatment technologies	14
SECTION III: WATER TREATMENT AND DOWNSTREAM EQUIPMENT	17
Approaches to equipment maintenance	18
Application considerations	19
Isothermal humidifiers	20
Adiabatic humidifiers and evaporative cooling	22
High-pressure atomization systems	22
Wetted media systems	23
DriSteem water softener systems	25
Softeners used with RO Systems	27
DriSteem RO systems	27
Testing the water quality	29
Water quality test strips	30
SECTION IV: ELECTRICAL CONDUCTIVITY OF WATER	33
Conductive ions in water	34
Conductivity and electrode humidifiers	34
SECTION V: CORROSION	37
Why corrosion matters to DriSteem	39
Corrosive water vs. scale-forming water	40
Corrosion-resistant properties of stainless steel	41
Galvanic corrosion	43
Intergranular (intercrystalline) corrosion	44
Stress corrosion	45
Crevice and pitting corrosion	46
Preventing corrosion	47
SECTION VI: TERMINOLOGY	49

Section I: Water basics




UNIQUE CHARACTERISTICS OF WATER

Water, H_2O , is one of the most interesting substances on earth, a substance that we all use in one way or another every day of our lives. We drink it to sustain life, we sweat it, we swim in it, and plants require it for growth. Up to 75% of our body weight is water, and almost the same percentage covers the earth's surface. Water freezes from top to bottom, not from bottom to top like other liquids. It is the only substance that exists in all three phases (solid/ice, liquid/water, and vapor/humidity) within the relatively small temperature range that we all live in. Why is this? What makes water so unique that it is the only substance that can exist in all three phases in such a small temperature range? And, how can we relate this to effects on our products?

HYDROGEN BONDS

Let's start with what every first-year chemistry student learns; that is the phenomenon of "hydrogen bonds," which are not true intramolecular (or covalent) bonds as in a molecular compound. Hydrogen bonds are given special prominence because they are the strongest intermolecular forces in nature. Hydrogen bonds allow certain molecules to act like miniature magnets that attract molecules to each other. Only hydrogen bonded with oxygen, nitrogen, or fluorine can exhibit hydrogen bonding due to the strong electro-negative characteristic of these atoms. The positive end of one molecule is attracted to the negative end of another molecule (see Figure 2-1).

FIGURE 2-1: HYDROGEN BONDS BETWEEN WATER MOLECULES




Hydrogen bond strength is an estimated 1/20 of covalent bond strength. Therefore, although strong, hydrogen bonds often make and break, combining with and releasing from other molecules.

BENT STRUCTURE

Water is a “bent” molecule. This allows a water molecule to possess a positive end (the end with the hydrogen atoms) and a negative end (the end with the oxygen atom). Since electrons carry a negative charge, the oxygen end of the molecule is more negative, and the hydrogen end is more positive, as shown by the shading in Figure 3-1. The result is a bipolar molecule with unique and very important properties. For example, water exists in both liquid and vapor states within the temperature range that supports human life.

Water is a liquid at room temperature, while most other substances with nearly the same or even higher molecular weight are vapors at room temperature. For example, water is lighter than both oxygen and nitrogen, but at room temperature oxygen and nitrogen are vapors that make up the major components of the air we breathe. These molecules are vapors because they do not possess hydrogen bonds.

Hydrogen bonds are also the reason a relatively high amount of energy is required to boil water into vapor, yet water can freeze into ice with relative ease. Hydrogen bonds also account for the high surface tension properties of water, as illustrated in Figure 3-2.

FIGURE 3-1: BENT STRUCTURE OF A WATER MOLECULE**FIGURE 3-2: HIGH SURFACE TENSION**


ATTRACTION TO OTHER SUBSTANCES

Hydrogen bonds not only allow intermolecular attraction between multiple molecules of water, they also allow attraction to other substances. Many of these substances have positive or negative charges, which makes them soluble in water. In fact, water dissolves more substances than any other liquid. That is why we call water the universal solvent.

Substances that are ionic (meaning they carry positive or negative charges), like salt, dissolve in water. See the salt crystal in Figure 4-1. Note that the negative ends of a water molecule surround positive ions (cations), and the positive ends of water molecule surround negative ions (anions). This creates hydration shells around the ions, causing particles to become evenly dispersed in the water.

Understanding water chemistry will help us to create more robust designs and effectively address water-related issues.

FIGURE 4-1: SALT CRYSTAL IN WATER



Water does not form hydration shells around nonpolar molecules. Because nonpolar molecules do not have partially positive and partially negative charges, they are not attracted to water molecules. Instead, they stay separate. Oil is nonpolar and does not dissolve in water.

IMPLICATIONS OF DISSOLVED SOLIDS

The amount of dissolved substances in a volume of water is referred to as total dissolved solids (TDS). The specific makeup of dissolved solids can significantly impact equipment maintenance requirements, performance, and even the potential for corrosion. For that reason, it is important to understand whether supply water has high TDS of a type that can cause scale formation over time, or whether it can cause equipment degradation due to corrosion. Understanding water chemistry will help us to create more robust designs and effectively address water-related issues. The remaining sections of this handbook will expand on these topics.

Section II: Water hardness



HARD WATER

What is hard water (sometimes called potable or tap water)? Technically, it is water that contains dissolved positive ions with multiple plus charges (polyvalent cations). Generally, these are calcium ions (Ca^{+2}) and/or magnesium ions (Mg^{+2}), but there can also be others, such as iron.

Typically, calcium ions are predominant, accounting for as much as 75% or more of the hardness. The precipitated form of the calcium ion contribution to hardness is calcium carbonate, which is known as lime scale or hard water scale. This scale adheres to surfaces and is difficult to remove, as discussed in the next subsection.

Where does water hardness come from? Following is a summary.¹

1. Water from rain enters the topsoil
2. Bacteria respiration (organic matter decomposition) produces CO_2
3. CO_2 and water react to form carbonic acid (H_2CO_3):

$$\text{CO}_2 + \text{H}_2\text{O} \leftrightarrow \text{H}_2\text{CO}_3$$
4. Limestone, which is calcium carbonate (CaCO_3) reacts with carbonic acid (H_2CO_3) to form calcium bicarbonate ($\text{Ca}(\text{HCO}_3)_2$) in water solution:

$$\text{CaCO}_3 + \text{H}_2\text{CO}_3 \leftrightarrow \text{Ca}(\text{HCO}_3)_2$$

Note: In water, $\text{Ca}(\text{HCO}_3)_2$ is ionic as Ca^{+2} and 2 HCO_3^-

Boiling water with these constituents creates a major potential for scale formation and maintenance issues in steam humidifiers because as hard water heats to the boiling point, precipitation of scale occurs.

¹ Mackenzie Davis and David Cornwell, *Introduction to Environmental Engineering* 5th Edition (New York: McGraw-Hill, 2012)

HARD WATER SCALE

Typically, substances become more soluble when heated unlike the process of scale formation. Although calcium carbonate is a solid, when dissolved in water at neutral or nearly neutral pH, it exists mainly as calcium bicarbonate.

Calcium bicarbonate: calcium ions (Ca^{+2}) and bicarbonate ions (HCO_3^{-})

While calcium bicarbonate is soluble in water at low temperatures, when heated to a boil, calcium carbonate forms. Calcium carbonate has very low solubility in boiling water and precipitates as scale. This is referred to as the inverse solubility of calcium carbonate. The process is shown below:

- Heat provides the energy to break down bicarbonate ions (HCO_3^{-}) in an endothermic process that initiates the reactions to produce the following:
 - carbonate ion (CO_3^{-2})
 - carbon dioxide (CO_2)
 - water (H_2O)
- CO_2 is less soluble at higher temperatures (or lower pressures) and evolves as a vapor, and the water stays behind as another water molecule.
- Calcium ions (Ca^{+2}) in the water combine with carbonate ions (CO_3^{-2}) once they are formed, and calcium carbonate (CaCO_3) precipitates due to low solubility:



Hardness is split into two groups:

- Group 1: Temporary hardness or carbonate hardness. This is what is shown in Figure 9-1. It is the group that we are concerned about because this is scale-forming hardness.
- Group 2: Permanent hardness or non-carbonate hardness. This group, by definition, contains hard water ions (such as calcium and/or magnesium) as in group 1, but it does not contain the bicarbonate ion. Therefore, this hardness does not form scale upon heating. It does not exhibit inverse solubility; rather, it follows standard rules of solubility and precipitates only when it becomes saturated.

Note: Total hardness is the sum of temporary and permanent hardness.

FIGURE 9-1: HARD WATER SCALE ON HEATING ELEMENTS



Scale must be removed from humidifier tanks, heaters, and heat exchangers to restore like-new performance. Removing scale by chipping and scraping with tools is time consuming and labor intensive.

FIGURE 9-2: POURING DE-SCALING SOLUTION INTO A HUMIDIFIER TANK



The easier and more thorough method for removing scale is by dissolving it with de-scaling solution.

ALKALINITY

Alkalinity is technically the capacity of an aqueous (water) solution to neutralize an acid. This means substances like bicarbonates, carbonates, and hydroxyl ions (OH^-) that make up the alkalinity in water can accept or give off hydrogen ions. These ion exchanges help to stabilize the pH of the water because pH is a function of hydrogen ions.

The temporary (scale-forming) hardness of water at or near neutral pH can be estimated from the bicarbonate alkalinity.

BICARBONATE ALKALINITY AND SCALE

The contribution of hydroxyl ions to alkalinity in water at or near neutral pH is negligible; however, alkalinity from carbonate species in water at or near neutral pH is mainly in the form of bicarbonate.

Because of that, the temporary (scale-forming) hardness of water at or near neutral pH can be estimated from its bicarbonate alkalinity. High concentrations of hard water ions and bicarbonate ions reacting with each other will produce scale.

Therefore, knowing the bicarbonate alkalinity of water can help us to estimate the scale-forming potential of water.

APPROACHES TO SOLVING THE HARD WATER PROBLEM

Maintenance is always a concern with equipment when hard water containing temporary hardness is present due to its scale forming potential, especially when water is heated to produce steam. That is why some building owners opt to soften their water. Others choose even more sophisticated water treatment systems to drastically reduce or even eliminate maintenance by using reverse osmosis (RO) or deionized (DI) water in their steam humidifiers.

SOFTENED WATER

Water softening is an ion exchange process that exchanges hard water ions like Ca^{+2} or Mg^{+2} for single-charged ions like sodium (Na^+) or potassium (K^+). Water softeners do not remove negative ions like bicarbonate and chlorides. So, what's the benefit? When in solution with bicarbonate, sodium ions do not exhibit inverse solubility. Even when the bicarbonate ion breaks down upon heating to form carbonate, it is still over 30,000 times more soluble than calcium carbonate. So, as shown below, instead of forming calcium carbonate scale, the sodium and carbonate ions stay in solution to much higher concentrations.




Softened water is one approach to preventing scale build up in steam humidifiers. Water softeners remove hard water cations and exchange them for softened water cations like sodium ions. Also, softening water does not appreciably change the conductivity of the water, because for every calcium ion (containing two positive charges) that is removed, it is replaced with two sodium ions, each of which have one positive charge.

Water softeners use resin beads with sodium (sometimes potassium) attached to them. An ion exchange occurs when hard water containing calcium and/or magnesium ions flows through the resin beads. The resin beads release sodium ions to the water while capturing the calcium and/or magnesium ions. See Figure 11-1.

Once the resin is depleted, it must be regenerated to flush out the captured hard water ions and replace them with a new source of sodium ions. This is done by using a salt solution (sodium chloride) from a brine tank. Once the regeneration process is complete, the system is rinsed to remove residual hard water ions and chloride ions from the salt, and the rinse water is sent to drain.

After being put back online, the newly softened water contains all the original substances that were in the incoming supply water minus the hard water ions that have been replaced with sodium ions. The process continues until the resin is again depleted of sodium, and another regeneration process occurs.

FIGURE 11-1: WATER SOFTENING PROCESS²



² Image courtesy of Andrea Kubisch, Courtney Korff (UCD), *Case Study: Hard Water* (LibreTexts, 2015), [Creative Commons](#)

REVERSE OSMOSIS (RO) WATER

To understand reverse osmosis, it is important to understand normal osmosis. Think back to high school biology and cells and electrolytes (which are biological dissolved solids). Cell walls are semipermeable membranes that allow the flow of water molecules through, but not many of the electrolytes because they are too large. If the concentration of electrolytes is higher on one side of the cell wall than the other, water flows through the cell wall to the side with more electrolytes. This flow of water dilutes the concentration of electrolytes on one side of the cell wall in an effort to equalize the concentration on both sides of the cell wall. This creates a pressure differential across the membrane called osmotic pressure. Normal osmosis is the process of water flowing from the less concentrated side of the cell wall to the more concentrated side of the cell wall.


RO water treatment does the opposite. It is a process that purifies water by flowing it through a semipermeable membrane from the more concentrated side to the less concentrated side, creating water that is nearly free of dissolved solids. Since this is not a natural process, mechanical pressure must be used. A pump is used to push the water through the membrane. In Figure 12-1, the left side shows natural osmotic flow, while the right side shows reverse osmotic flow.

RO water treatment creates two flows, the concentrate (the source water side of the membrane) and permeate (the downstream side of the membrane with clean water). The concentrate flow carries the concentrated solids to the drain, and the permeate flow consists of purified water that can be stored and used by downstream equipment.

Normal osmosis is the process of water flowing from the less concentrated side of the cell wall to the more concentrated side of the cell wall.

Reverse osmosis is the opposite in that it pushes water through a semipermeable membrane from the more concentrated side to the less concentrated side.

FIGURE 12-1: NORMAL OSMOSIS AND REVERSE OSMOSIS



DEIONIZED (DI) WATER

The main method used in the industry to create DI water from water containing TDS is by using ion exchange. This is somewhat similar to a softener, but much more thorough. Positive ions are called cations and negative ions are called anions. DI water treatment systems use two types of resin and removes all cations and anions.

Page 10 and 11 explains that in water softening, sodium (Na^+) ions are released during the capture of calcium and magnesium ions. In the deionization process, the cation resin bed is used for positive ion removal and a hydrogen (H^+) ion is released. In the anion resin bed, used for negative ion removal, a hydroxyl (OH^-) ion is released. The two released ions, H^+ and OH^- , form water (H_2O). The result is DI water—all TDS removed—for downstream equipment requiring very clean water.

Care must be taken to replace spent DI water treatment system resin beds with regenerated resin beds, or pass-through will occur, resulting in impure water downstream. Spent cation and anion resin beds are regenerated with a strong acid (containing H^+ ions) and a strong base (containing OH^- ions) similar to using salt to regenerate a softener.

OTHER WATER TREATMENT TECHNOLOGIES

There are many water treatment technologies, new and old, being used in various industries. While it is not the purpose of this handbook to go into detail on all technologies, following are comments on a few.

Chemical treatment

Municipal water treatment systems use a large chemical treatment process called lime softening to at least partially soften the water sent out to the community. They also provide chlorination to prevent bacterial growth in the water supply.

Physical water treatment

The goal of physical water treatment (PWT) is to change the crystal structure of the calcium carbonate from calcite to aragonite. Calcite is a lower-energy structure that forms a hard, scaly deposit requiring mechanical or chemical cleaning to remove. Aragonite, on the other hand, forms more of a powdering deposit that, if managed properly, may help to avoid or lessen the maintenance burden on equipment. There are various approaches to PWT, including template assisted crystallization (TAC) and various magnetic techniques.

Capacitive deionization

Capacitive deionization (CDI) uses capacitance to capture the ionic solids when water flows through the system. Positive ions flow toward a negative electrode, and negative ions flow toward a positive electrode. Reversing the polarity of the electrodes releases the ions, which can then be flushed to the drain.

Sequestering agents

Sequestering agents are used to form a “shield” around the ions to help prevent them from reacting with other ions and forming scale. Over time, sequestering agents form a type of flocculent in the water that can be drained or filtered out.

Notes

Section III: Water treatment and downstream equipment



Humidification and evaporative cooling require transforming water into vapor, so it is not surprising that water can have a great impact on system performance and maintenance. In order to maintain relative humidity (RH) and other space requirements while keeping systems running the way they were intended, it is important to understand how water types can affect those systems.

APPROACHES TO EQUIPMENT MAINTENANCE

Maintenance is a major concern for many building owners and facility managers. It is a constant struggle for customers who process water, especially if that water is very hard. So, how do customers manage hard water scale formation? The three primary approaches to maintenance that DriSteem customers take are in-process management, post treatment, and pretreatment.

In-process management

In-process management is managing the system during use by periodically draining the tank. Draining frequency and duration are based on water type, tank size, and the volume of water boiled or evaporated. Systems using hard water are designed to perform well with a moderate amount of scale; however, the in-process management approach to equipment maintenance has limited effect in steam humidifiers due to inverse solubility when hard water is boiled to produce steam.

Post treatment

The post-treatment approach is to remove scale on a scheduled or as-needed basis. This approach requires shutting the system down and manually removing scale with tools or dissolving scale with de-scaling solution.

Post-treatment maintenance can be costly and can contribute to future corrosion issues. Scraping and chipping can compromise the stainless steel chromium passivation layer, and de-scaling solution must be properly neutralized and rinsed from the tank.

Pretreatment

Pretreatment keeps the system up and running as much as possible while minimizing downtime for maintenance. This approach requires additional equipment but, for some customers and for some product lines, it is essential.

Typical pretreatment technologies include RO, DI, and softening systems. Other technologies, such as sequestering agents and physical water technologies, are sometimes used in certain industries.

Factors that affect the amount of scale produced and the maintenance frequency include:

- Concentration of temporary hardness in the water
- Temperature and/or pressure conditions
- Volume of water boiled (throughput)

APPLICATION CONSIDERATIONS

Customers need to evaluate what type of system they need to meet their specific needs. Some applications are critical and must have humidity production available whenever called for. Some components, such as atomizing nozzles, cannot tolerate any scale buildup and require DI or RO water.

On the other hand, space conditions for comfort applications are broad and do not require tight control. Customers with non-critical applications may opt for hard water, or if they want to lessen the effort and frequency of maintenance, they may opt for softened water. Customers with treated water on-site and enough capacity to supply their humidification systems may want to consider using their on-site water.

Customers with tap water only and applications requiring water treatment can obtain water softening and RO systems from DriSteem.

ISOTHERMAL HUMIDIFIERS

Figures 20-1 through 20-3 are meant to show the varying effects of using hard, softened, and RO water in humidification systems. Note the solubility difference of calcium carbonate scale from hard water versus sodium carbonate from softened water.

Hard water forms scale requiring cleaning with chemicals or mechanical means.

- Upon heating to create steam, calcium carbonate is formed via inverse solubility.
- Calcium carbonate is a hard scale.
- Calcium carbonate solubility is very low: 0.0014 g/100 cc at 77 °F.

Softened water does not form hard scale and may extend maintenance intervals by a factor of three.

- Sodium has replaced calcium in the softener via ion exchange.
- Sodium carbonate is a soft, powdery substance.
- Sodium carbonate is over more than 30,000 times more soluble than calcium carbonate: 45.5 g/100 cc at 77 °F.

RO water provides nearly pure water which significantly reduces maintenance.

- RO systems provide water with approximately 98% TDS removed.
- RO systems use replaceable membranes and filters and may eliminate significant humidifier maintenance.
- DriSteem uses extra-low-energy membranes in all RO systems to maintain higher permeate water flow at lower temperatures.

DriSteem rates permeate flow at 50° F.

All of DriSteem's isothermal humidifiers can use hard, softened, DI, or RO water except for XT Series electrode humidifiers. Electrode humidifiers require conductive water and, therefore, cannot use water with little or no TDS, such as DI or RO water.

FIGURE 20-1: HARD WATER SCALE ON HEATERS AND TANK



FIGURE 20-2: SOFTENED WATER RESIDUE IN HUMIDIFIER TANK



FIGURE 20-3: RO WATER LEAVES NO RESIDUE ON HEATERS AND TANK



As discussed in Section 2, scale formation requires maintenance and results in equipment downtime, and it is a common problem with hard water. In critical applications when humidity must be available on demand, DI or RO water is generally used so as to avoid the maintenance downtime due to scale build up.

Softened water too, helps avoid maintenance downtime. It does not form scale, and humidifiers typically run three times longer between maintenance shutdowns than systems using hard water. However, if corrosive agents such as chlorides are present, corrosion effects could show up faster with softened water than with hard water. How can this be? Ironically, the scale from hard water can provide a “pseudo barrier” that prevents corrosive agents from reaching vulnerable areas (such as weld joints) in a tank. This barrier can actually help to extend the life of the tank.

Properly maintained DI water systems do not have dissolved solids. In theory, they provide the cleanest water for use in humidifiers; however, carbon dioxide, which is present in the atmosphere, can dissolve in water and create carbonic acid. This can lower the pH into the acidic range making some systems vulnerable over time to acidic attack in susceptible areas.

RO systems remove as much as 98% of the dissolved solids, but a small amount does pass through. If any corrosive agents such as chlorides are in the pass-through, they can concentrate in the tank water because they do not vaporize during the boiling process. In such cases, drain intervals should be established based on DriSteem guidelines for supply water, even if the humidifier is configured for DI or RO water.

ADIABATIC HUMIDIFIERS AND EVAPORATIVE COOLING

HIGH-PRESSURE ATOMIZATION SYSTEMS

DriSteem's High-pressure atomization system requires RO water to prevent the nozzles from scaling and to prevent white deposits from TDS being distributed in the conditioned space.

Supply water to the RO system must be softened to prevent scale buildup on the RO membranes. Scale would shorten membrane life.

Thin film composite (TFC) extra-low-energy membranes are used in DriSteem RO systems. To prevent oxidation from chlorination of the water supply and shortened membrane life, a carbon filter/dechlorinator is required upstream from the RO system. Tank-style carbon filters/dechlorinators are offered in multiple sizes to match softener capacities. They contain large quantities of carbon and employ backwash cycles to rinse the filter media and send the rinse water to the drain. Tank-style carbon filters/dechlorinators can be used for larger capacities up to 5500 pph.

Smaller RO systems (up to 500 pph) can get by with a cartridge-style carbon filter/dechlorinator. Because cartridge-style filters do not have a backwash cycle, they need to be changed regularly.

A sediment filter is also used with all DriSteem RO systems to capture suspended solids in the supply water.

WETTED MEDIA SYSTEMS

DriSteem's Wetted media system uses hard water and Munters media. RO water is generally not considered for wetted media systems because nearly pure water can become aggressive if the pH falls into the acid range from absorbing CO_2 , thereby forming carbonic acid. RO water that becomes acidic over time could degrade the structural supports in the media and cause it to collapse.

Cycles of concentration

To use hard water most effectively, it is necessary to determine the cycles of concentration (COC) to maintain in the water tank for optimal performance of the Wetted media system. The COC determination depends on the following supply water quality parameters:

- Calcium hardness (as CaCO_3)
- Total alkalinity (as CaCO_3)
- Conductivity
- Wet bulb temperature

Note: Other parameters such as chlorides and silica content may also be of interest; not for determining COC, but for preventing corrosion or silica deposits from forming if these constituents are present in significant enough quantities.

DriSteem's media works well with hard water that has some amount of scale potential. The trick is to determine the correct COC range for not too much and not too little scale.

DriSteem can help determine the COC range that should be targeted given the supply water quality parameters listed above. The Wetted media system's Vapor-logic controller manages the drain water volume and frequency to keep the system within the selected COC range.

Cycles of concentration indexes

There are multiple methods for determining the scaling potential of water. Examples of such methods are the Langlier Index, Ryznar Index, and Puckorius Scaling Index. DriSteem uses the Puckorius Scaling Index as a factor in determining the COC range for the wetted media system.

The COC target range is determined by using equations from Munters with variable inputs for hardness, alkalinity, conductivity, and wet bulb temperature. Table 24-1 shows the values for the Langlier Index, Ryznar Index, and Puckorius Scaling Index. Note that target values should fall in the low-scale-forming, low-scale-dissolving area in the table.

The target range using the Puckorius Scaling Index is from 6 to 7, with 6 representing low scale-producing potential and 7 representing low scale-dissolving potential. This is the "sweet" spot for the media. The pH range should be from 7 to 9. Note that this is not acidic water which is important for the reason given earlier—media degradation.

Table 24-1:
COC range

Langlier Index	Ryznar Index	Puckorius Scaling Index	Water activity
3	3	3	High Scale forming
2	4	4	
1	5	5	
0.5	5.5	5.5	
0.2	5.8	5.8	
0	6	6	Low
-0.2	6.5	6.5	Low Scale dissolving
-0.5	7	7	
-1	8	8	
-2	9	9	
-3	10	10	High

DRISTEEM WATER SOFTENER SYSTEMS

Water softener systems can be used directly with isothermal humidifiers as well as for producing softened water for input to RO systems.

The softener system needs to be sized for the equipment directly downstream:

- If the equipment is an isothermal humidifier, the capacity of the softener must meet the humidifier requirements.
- If the equipment is an RO system from an isothermal humidifier or high pressure atomization system, the softener needs to meet the needs of the RO system, which is more than the needs of the humidifier. That's because the RO system does not send all the water it processes to the humidifier. It sends only the purified permeate water to the humidifier and sends the concentrate water to the drain. Given this understanding, it is possible for an isothermal humidifier to require a different sized softener based on whether the softener is used directly with the humidifier or via an RO system.

Resin and regeneration

Softener resin can hold a maximum of 30,000 grains of hardness per cubic foot of resin. Generally, it is a good practice to give some sort of safety margin on this number to prevent hardness pass-through under certain conditions. For example, using less salt to regenerate the resin will result in less-than-complete regeneration and, thus, less capacity.

DriSteem softeners come preset for a recommended 10 pounds of salt usage per cubic foot of resin. Table 25-1 lists typical resin derate factors based on the softener's salt usage setting.

Table 25-1:
Typical resin derate factors

Salt usage (pounds per cubic foot)	Resin capacity (grains per cubic foot)
15	30,000
10	29,000
7.5	25,700
5	20,000

To initiate a regeneration based on the volume of water, it is necessary to know the hardness. Given the capacity of the resin shown in the table above, one can calculate the gallons of water needed to reach the capacity of the softener. This is the volume that can be programmed into the softener to initiate a regeneration cycle. A timed regeneration is generally used as a backup for volume regeneration. Typically, a timed regeneration should not exceed 14 days, so if the volume is not reached within the timed regeneration period a regeneration will automatically occur at the end of the time period.

Flow rate

Flow rate through a softener is also important. Though rare, a phenomenon called “channeling” can occur under very low flow rates. This results in lowering the resin capacity of the softener due to water trickling through the resin and not using the full capacity of the total volume of resin.

Humidifiers drawing fill water from an RO storage tank should not cause channeling in upstream water softeners, because the RO storage tank fills at an adequate flow rate. Channeling in the water softener resin does not occur when humidifiers draw water (even at a trickle) from the storage tank. However, if a softener is dedicated for humidifier use, and the humidifier flow requirements are low, channeling can occur.

If channeling occurs, regeneration cycles may need to be more frequent. Another problem with very low flow rates is that the impeller in the water meter might not rotate, so flow is not measured. The solution to unmetered water flow is to set up regeneration intervals based on time instead of volume. Clearly, low-flow conditions are not ideal. If any of the situations described above occur, then it is best to look for alternative water treatment options. Alternatives include small, point-of-use softening systems that are designed for low-flow conditions.

Some of DriSteem’s smaller humidifiers have restrictive orifices to reduce flow so as not to quench the boil. Others employ a pulsed-fill approach. These slow-filling humidifiers will need special consideration in order to assure proper water softener performance, especially when using a dedicated softener from DriSteem. If a softener supplies multiple humidifiers, low-flow conditions might be eliminated but could still occur. Even with multiple humidifiers, there could be times when only one humidifier is running at a time.

For best softener performance some companies suggest that the flow rate range through the softener is from 5 to 15 gpm/ft² of resin surface. The Dow Chemical Company manufactures water softener resin and specifies a minimum flow of 2 gpm/ft² of resin surface.

SOFTENERS USED WITH RO SYSTEMS

Although RO systems remove about 98% of dissolved solids, some solids still pass through. If a softener is not used to treat the water prior to sending it to the RO system, the pass-through water may contain enough hard water ions to form scale over time. Care must be taken to assure that softened water is supplied to the RO system to prevent equipment from being affected by scale buildup, as scale may affect operation of the RO system, requiring unwanted maintenance.

As explained on page 25, sizing a softener to match an RO system may result in a larger softener than one sized for a downstream device using only softened water.

DRISTEEM RO SYSTEMS

DriSteem manufactures and sells two series of RO systems, the 400 series and the 200 series. Both series use thin film composite (TFC) extra-low-energy membranes, which allow for greater permeate production at colder temperatures where DriSteem products might be used. All membranes from DriSteem are rated for use in DriSteem RO systems at 50 °F, where the industry standard for rating RO membranes is at 77 °F. The drop in permeate production is quite significant at lower temperatures, so this is why DriSteem has chosen to only offer extra-low-energy membranes in all RO systems.

Table 28-1 shows the impact of temperature on TFC membranes. Note that the table does not represent **extra**-low-energy membranes, but only typical TFC low-energy membranes. At 50 °F extra-low-energy membranes produce about 50% more permeate than low-energy membranes, dramatically reducing the negative impact due to cold water use. This allows for larger capacities with fewer membranes, which can reduce overall cost and the size of product.

At 50 °F extra-low-energy membranes produce about 50% more permeate than do low-energy membranes, dramatically reducing the negative impact due to cold water use.

Table 28-1:
Permeate flow and temperature

Feed water temperature		Temperature correction factor for thin film	Feed water temperature		Temperature correction factor for thin film	Feed water temperature		Temperature correction factor for thin film
°C	°F		°C	°F		°C	°F	
1	33.8	3.64	18	64.4	1.29	35	95.0	0.73
2	35.6	3.23	19	66.2	1.24	36	96.8	0.71
3	37.4	2.82	20	68.0	1.19	37	98.4	0.69
4	39.2	2.41	21	69.8	1.15	38	100.4	0.67
5	41.0	2.00	22	71.6	1.11	39	102.2	0.65
6	42.8	1.79	23	73.4	1.08	40	104.0	0.63
7	44.6	1.58	24	75.2	1.04	41	105.8	0.61
8	46.4	1.37	25	77.0	1.00	42	107.6	0.60
9	48.2	1.16	26	78.8	0.97	43	109.4	0.58
10	50.0	1.00	27	80.6	0.94	44	111.2	0.56
11	51.8	0.89	28	82.4	0.91	45	113.0	0.54
12	53.6	0.78	29	84.2	0.88	46	114.8	0.53
13	55.4	0.68	30	86.0	0.85	47	116.6	0.51
14	57.2	0.59	31	87.8	0.83	48	118.4	0.49
15	59.0	0.51	32	89.6	0.80	49	120.2	0.47
16	60.8	0.44	33	91.4	0.77	50	122.0	0.46
17	62.6	0.38	34	93.2	0.75			

Temperature correction factor indicates almost double the capacity at 77 °F, compared to at 50 °F.

TFC membranes are susceptible to oxidation from chlorine in the water, so chlorine must be removed from the supply water prior to the water coming in contact with the membranes. A carbon filter is used to remove the chlorine. For small systems, a cartridge-type carbon filter can be used and changed as needed. Larger systems use tank style carbon filters/dechlorinators that are sized comparable to softeners they are used with in order to maintain similar flows.

DriSteem RO systems come with a pressurized storage tank as standard equipment. An atmospheric storage system with UV light and pump is also available on a skid as an option. DriSteem's Vapor-logic controller is used to control every system.

400 Series RO systems are designed for larger loads from 250 pph to 5500 pph and use from one to twelve 4" x 40" extra-low-energy membranes.

200 Series RO systems are designed for smaller loads up to 300 pph and use from one to three 2½" x 21" extra-low-energy membranes.

TESTING THE WATER QUALITY

Water quality is an important factor in RO system product lifespan:

- Membranes can scale up or plug up in RO systems treating water that is high in TDS.
- Membranes can oxidize and fail in RO systems treating water containing chlorides.


Knowing what to test for is also important. Typical tests of municipal water include the following:

- Chlorides
- Alkalinity (carbonate)
- TDS
- Total hardness
- pH
- Conductivity

Page 30 provides instructions for obtaining and properly using water quality test strips.

WATER QUALITY TEST STRIPS

- Carbon filters in the water treatment system should be changed regularly to maintain proper pressure and flow and water quality.
- The carbon filter removes chlorine. Change the carbon filter when chlorine from supply water starts to pass through. Check regularly for chlorine pass through.
- To check for chlorine, obtain a water sample from the concentrate drain line and test the water. If chlorine is present, change the carbon filter and record the interval to estimate the next carbon filter change.
- For best results, test water chlorine every two weeks.
- To order Water Quality Test Strips, contact your local DriSteem rep, or call 1-800-328-4447.



DIRECTIONS:

- Dip entire strip into water for 1 second (or pass under water stream), remove. Do not shake excess water from the test strip. Hold the strip for 30 seconds.
- Compare TOTAL HARDNESS, TOTAL ALKALINITY and pH pads to color chart to the left.
- Dip strip into the water again and move back and forth for 30 seconds (or hold two chlorine pads under water stream for 10 seconds).
- Compare CHLORINE pads to color chart to the left.
- Track results in the chart below.
- Change the carbon cartridge filter once chlorine is detected in the concentrate water of the water treatment system.

Table 30-1:
Water quality test log

Date tested	Total chlorine ppm	Free chlorine ppm	Total hardness	Total alkalinity	pH
Week 1 _____					
Week 3 _____					
Week 5 _____					
Week 7 _____					
Week 9 _____					
Week 11 _____					

Notes

Section IV: Electrical conductivity of water



CONDUCTIVE IONS IN WATER

Electrical conductivity in water is proportional to the concentration of conductive ions in the water. The higher the concentration of conductive ions, the higher the conductivity of the water.

Resistivity is the inverse of conductivity. Ultra-pure water has so few conductive ions that it is, for all practical purposes, infinitely resistive.

Conductivity is determined by the following:

- Charge on the ions
- Size of the ions
- Temperature of the water

Without doing extensive chemical testing, TDS can be estimated from conductivity. Since different ions can have different charges, translating conductivity to TDS actually depends on the items listed above. Most estimates, including what is used in TDS sensors, use a factor of 50% when converting from microsiemens per centimeter to TDS in parts per million. For example, if the conductivity of a water sample is 100 $\mu\text{S}/\text{cm}$, the estimated TDS is 50 ppm. In most situations this estimate is sufficient.

CONDUCTIVITY AND ELECTRODE HUMIDIFIERS

Conductivity and resistivity are critical to the operation of an electrode humidifier. In electrode humidifiers, steam output is directly related to the resistance of the water in the steam cylinder and, therefore, to the conductivity of the water between the electrodes. Higher water levels cover more electrode surface and result in more steam; lower water levels cover less electrode surface and result in less steam.

Water conductivity and water level both correlate to steam output. Some manufacturers of electrode humidifiers employ a proprietary algorithm to monitor conductivity and manage drain and fill cycles to optimize humidifier performance and provide proper steam output.

Water containing temporary hardness precipitates scale, removing conductive ions from solution. This results in fewer required drain-and-fill cycles to manage conductivity than would be required with softened water. As a result, water containing temporary hardness generally provides more consistent steam output and less energy usage in electrode humidifiers than softened water can provide.

Hard water is generally the preferred water type for electrode humidifiers; it provides the most consistent steam output and results in less energy and water usage.

However, it should be understood that if the hardness is all or nearly all permanent hardness with little to no temporary hardness, the hard water will not form calcium carbonate scale to slow the growth in conductivity. This will result in a humidifier performing more closely to a softened water situation than a more typical hard water scenario when the hardness is temporary.

On the other hand, if the water contains temporary hardness but few dissolved solids to contribute to conductivity in the supply water, then when the temporary hardness precipitates out of solution the conductivity may actually drop after initially increasing. Since the calcium carbonate precipitate does not have significant solubility in water, and there are not many other dissolved solids present to contribute to conductivity, there is no alternative to having the conductivity drop until the few dissolved solids concentrate enough to overcome the precipitation of the temporary hardness. This is somewhat rare, but it can happen. Understanding this is critical to knowing what is going on. Water quality lab analyses are invaluable in helping to understand whether this phenomenon is occurring.

As the water in an electrode humidifier cylinder heats up, the conductivity increases (Figure 35-1). When it boils into steam, the concentration of the conductive ions increases until it reaches a threshold that triggers a drain-and-fill cycle (Figure 35-2). This rids the cylinder of highly conductive water and replaces it with less conductive supply water.

The more conductive the supply water and the higher the demand, the more quickly the threshold is reached, and the more frequently the cylinder automatically drains and fills to stay within the parameters for the proper steam output. The frequency and duration of the drain-and-fill cycles is proportional to the conductivity of the supply water. Generally, less conductive supply water takes somewhat longer to reach full output at startup but requires less frequent drain-and-fill cycles. This results in more consistent steam output over time and more efficient use of energy and water.

FIGURE 35-1: ELECTRODE HUMIDIFIER BOILING WATER





FIGURE 35-2: ELECTRODE HUMIDIFIER FLUSHING CONDUCTIVE WATER



Section V: Corrosion



Everyone has seen degradation of metals, including rust formation, throughout their lives. Just what is corrosion? It's a natural process that causes metal degradation/disintegration due to chemical reactions from its surroundings. Corrosion will occur when the right set of ingredients are available to convert a metal to a more chemically stable form, such as an oxide. Iron corrodes to form iron oxide (rust). Corrosion can be caused by either of the following:

- Direct chemical attack followed by oxidation
- Electrochemical oxidation, where a potential difference is set up within or between metals by creating a miniature electrochemical cell. Metals react and form an oxide or some other compound. The following three essential ingredients are required:
 - Anode
 - Cathode
 - Electrolyte (for example, conductive water)

Metal corrodes at the anode. The anode is the "active" site where the corrosion (oxidation) takes place. It enters the electrolyte as a positive ion, and electrons travel toward the cathode.

The cathode completes the electrical circuit and is not consumed. The cathode is the "protected" site where the metal does not corrode.

The electrolyte provides the corrosive medium, such as chlorides in water, and the electrical path through the water via ion flow.

WHY CORROSION MATTERS TO DRISTEEM

DriSteem must understand corrosion for the following reasons:

- Prepares us to understand how water chemistry can negatively impact the reliability of our products
- Enables us to create water quality guidelines, which are needed to protect our equipment and mitigate corrosive effects on our products
- Equips us to discover innovations for improving product reliability in corrosive environments

Several factors can influence the potential for corrosion in our products. Some of these corrosion influencers are listed below:

- Temperature: High temperatures increase the rate of corrosion.
- Flow rate: Low flow rates can allow oxygen to concentrate in “cells” and enhance corrosion potential.
- pH: Low pH (less than 7) is acidic and creates the potential for corrosion. CO₂ dissolved in water forms carbonic acid, which can lower pH.
- TDS: High TDS contribute to conductivity, enhancing the electrolytic effect and increasing the rate of corrosion.
- Alkalinity
- Hardness
- Oxidizing agents, such as oxygen
- Corrosive agents: Chlorides, for example, are aggressive ions that can accumulate and concentrate in cavities, contributing to corrosion.
- Bacteria: Among potential mechanisms, bacteria can release CO₂ to form carbonic acid and enhance corrosion potential (microbiologically influenced corrosion).
- Electromotive potential: Dissimilar metals can create galvanic corrosion potential.

Among these, the primary factors include:

- Alkalinity
- Hardness
- pH
- Corrosive agents

CORROSIVE WATER VS. SCALE-FORMING WATER

Water can be categorized in many ways. For the purpose of this handbook, water is in two groups: corrosive water and scale-forming water. Scale-forming water is less corrosive because the process of forming scale removes/evolves acid-forming CO_2 . As a side benefit, scale also provides a certain amount of protective barrier against corrosive agents.

Corrosive water characteristics include:

- Low pH
- Non-carbonate hardness (permanent hardness)
- Low alkalinity
- Concentrated corrosive agents to high levels

Scale-forming water characteristics include:

- High pH
- Carbonate hardness (temporary hardness)
- High alkalinity
- Low levels of corrosive agents

A general summary or take-away from the two lists above is as follows:

- Low-pH water has excess H^+ ions (acid) to enhance corrosion.
- High-pH water lowers the solubility of calcium carbonate (CaCO_3), making it more likely to form scale.
- Low-alkalinity water lacks buffering capacity, creating less ability to stabilize pH. Following are two consequences:
 - Makes it harder to deal with acidic/corrosive conditions
 - Limits scale potential that can act as a barrier to corrosion
- Corrosive agents, like chlorides, are aggressive, prevalent, and can concentrate.

CORROSION-RESISTANT PROPERTIES OF STAINLESS STEEL

Moving away from water characteristics and their corrosive effects for a moment, there are a few points to be made about stainless steel, since that is what DriSteem uses in most humidifier products, particularly the tanks and some heat exchangers.

- Corrosion resistance in stainless steel is due to its ability to form a protective layer.
 - The surface of the metal forms an invisible, “passive” film of chromium oxide.
 - Passivation is instantaneous in the presence of oxygen.
 - Stainless steels perform well under oxidizing conditions where other materials do not.
- Halogen salts (chlorides) can be a problem.
 - They are soluble, “active” ions and good electrolytes, which makes them good corrosion agents.
 - They are common in nature and are likely to be in natural waters.
 - Penetration of the protective passive film on stainless steel by chlorides is affected by concentration, temperature, and stress.
- 300 series (austenitic) stainless steel is resistant to but not impervious to chlorides.
 - Above 50 °F it is susceptible to chlorides at concentrations of only a few parts per million.
 - Stress corrosion can occur at higher temperatures with chloride levels as low as 10 ppm.
 - Chlorides can concentrate in crevices (up to 100x).
 - Processing parameters, such as chromium depletion (sensitization), can affect corrosion resistance.

- Stainless steel composition (various grades) can help to minimize corrosion in given environments.
 - Austenitic stainless steel (300 series) contains chromium-nickel for corrosion resistance.
 - Lower carbon content reduces the potential for chromium carbide formation and precipitation in the grain boundaries during the welding process.
 - Removal or depletion of chromium reduces corrosion resistance/passivation of steel near the weld joint. The weld joint is the heat-affected zone and more susceptible to corrosive attack. See Figure 42-1.
 - Solution annealing at very high temperature (1600°F or higher) can re-distribute the carbon and the chromium into the steel. To allow for repassivation of the chromium, the temperature must be dropped quickly (quenched) to prevent forming chromium carbide again.
 - 316 stainless steel contains molybdenum for improved resistance to chloride crevice and/or pitting corrosion.

The following subsections provide an overview of some types of corrosion that can occur, including:

- Galvanic corrosion
- Intergranular or intercrystalline corrosion
- Stress corrosion
- Crevice and pitting corrosion

FIGURE 42-1: STAINLESS STEEL CORROSION EXAMPLES



GALVANIC CORROSION

Galvanic corrosion (Figure 43-1) can occur when two different metals are in contact with each other via an electrolyte, with the following paths present:

- Ionic
- Electrically conductive

More active metals corrode and dissolve. Stainless steels are generally cathodic to other metals, but the degree of passivation can have an impact on corrosion resistance.

To help mitigate for galvanic corrosion, electrical isolation of the two metals is sometimes used. The isolation barrier must, of course, be non-conductive. Another approach is sacrificial anodes made of zinc or magnesium. These metals are more active than most others, so they can be intentionally corroded to protect other metals.

Table 43-1 lists metals in order from active (anodes) to noble/less active (cathode). This list is called the galvanic series of metals. The greater the separation in the galvanic series, the greater the potential difference, which means the greater the opportunity for corrosion.

Figure 43-1 shows the flow of electrons to complete a circuit using an electrolyte and an anode and cathode that are connected by a conductive path.


FIGURE 43-1: GALVANIC CORROSION



Table 43-1:
Galvanic series of metals

Anode (more active/corroded end)
Magnesium
Zinc
Aluminum
304 Stainless (active)
316 Stainless (active)
Lead
Tin
Brass
Copper
Bronze
304 Stainless (passive)
316 Stainless (passive)
Silver
Gold
Platinum
Cathode (more noble/protected end)

FIGURE 43-1: ION AND ELECTRON FLOW BETWEEN ANODE AND CATHODE




INTERGRANULAR (INTERCRYSTALLINE) CORROSION

Intergranular corrosion, as the name implies, occurs at or near the grain boundaries of the metal. When chromium carbide precipitates in the grain boundaries (the space between the grains), it renders the adjacent areas susceptible to corrosion. This known in the industry as “sensitization.” Sensitization occurs at temperatures between 800°F and 1650°F and is a common result of welding. Once sensitized, corrosion can occur in these areas near the weld joints if the water chemistry is suitable. Acidic water and chlorides are the main contributors.

How can this mechanism be minimized in real applications? There are several ways to address this issue but some are less desirable than others. The following are some examples:

- Do not allow the water quality to create a corrosive environment. Water treatment can be applied and, depending on the supply water constituents, draining to mitigate for concentration build up should also be considered.
- When welding tanks and heat exchanges, institute an annealing process to re-dissolve the carbon and chromium, and quench the metal to reduce the heat quickly so as not to reform chromium carbide. This will allow the chromium to be available for repassivation.
- Use low carbon stainless steel (“L” grade). Less carbon will offer less opportunity for chromium carbide precipitation, resulting in less opportunity for sensitization.
- Use another type of stainless steel that will have more corrosion resistance. As mentioned earlier, 316 stainless steel is an alloy that has molybdenum that can combat corrosion caused by chlorides. Other stainless steel alloys that contain elements like niobium or titanium can act as a stronger carbon “getter” than chromium to assist with corrosion prevention.

FIGURE 44-1: INTERGRANULAR CORROSION EXAMPLES




STRESS CORROSION

Stress corrosion, often referred to as stress corrosion cracking (SCC), occurs when the metal is under stress from bends or other stress agents while in the presence of a corrosive agent. The stress can be applied from an external source such as a bolt or from residual processing stress from welding. If intergranular corrosion (transgranular corrosion can also occur) is occurring, the stress will accelerate the corrosion process. The main culprit is chloride solution coupled with stress and temperature. The chloride can enter the process through a variety of compounds such as sodium chloride (NaCl), zinc chloride (ZnCl₂), and others. Under magnification SCC looks like a dendritic structure with the crack forming from a stress riser location (see Figure 45-1).

Factors that can affect stress include the hardness level of the metal (the cold rolled hardness) as well as assembly requirements like bolts, bends, and welding.

Stress corrosion cracking can be reduced or eliminated by either reducing or eliminating stress on the metal or removing corrosive agents from the water. Adding elements to the metal provides little value.

FIGURE 45-1: STRESS CORROSION EXAMPLES



CREVICE AND PITTING CORROSION

Corrosion occurs where passivation is removed/destroyed (resulting in pits) or where cavities/crevices are built into a product, especially where the crevices are on the water side and welded. These locations become anodic (corrosion susceptible) with respect to the passivated areas. This leaves small, active areas prone to attack. The larger the difference between the anodic area and the cathodic area, the greater the rate of corrosion.

Contributors to crevice and pitting corrosion include the following:

- Stagnant solutions preventing oxygen from getting to susceptible areas to provide passivation
- Chlorides and acids filling pits and crevices

It is widely believed in the industry that the crevice and pitting corrosion mechanism follows the sequence below:

1. Chlorides penetrate the passivation layer and start the corrosion process, which is accelerated if pH is low.
2. Lack of fluid flow (flushing) in the area of the pit or crevice prevents oxygenation of the exposed metal, so the corrosion progresses uninhibited.

Note: Welded joints are particularly susceptible when chromium is depleted at or near the weld joint (the heat affected zone) and cannot be re-oxygenated or re-passivated.

Some ways to combat this mechanism are listed below:

- Reduce the severity of corrosion by adding molybdenum, and reduce the carbon content of the stainless steel (for example, 316L).
- Remove the corrosive agents via water treatment.
- Remove the crevices in the design process, or completely seal the crevices with non-porous material.

FIGURE 46-1: CREVICE AND PITTING CORROSION



PREVENTING CORROSION

A theory of crevice corrosion has been presented in a study developed by a partnership between steel manufacturing companies and automobile manufacturing companies.¹


While there are varying opinions on the mechanism of crevice corrosion, one potential mechanism has been presented by this group. And while mechanism is complex, a short summary follows:

1. Oxygen is depleted in a crevice while being more abundant at the surface.
2. The oxygen concentration gradient induces an oxidation/reduction reaction that results in metal oxidation forming positive metal ions.
3. The positive charge of the metal ions is balanced by attracting negatively charged ions, like chlorides, into the crevice.
4. Hydrolysis of metal chloride forms acid and lowers the pH, which results in an auto-catalytic process.
5. The auto-catalytic process then promotes more metal ion formation, followed by more chloride migration to the crevice, followed by more acid production, followed by more corrosion, and so on.

The process continues to repeat itself as long as all the ingredients are present.

Figure 47-1 shows this mechanism.

FIGURE 47-1: REDUCING CORROSION



¹ A Guide to Corrosion Protection: For Passenger Car and Light Truck Underbody Structural Components, 1st Edition (Southfield, MI: Auto/Steel Partnership, 1999)

What would we, at DriSteem, really like to have to prevent corrosion in our products? In an ideal world we would like the following:

- No sensitization
- No metal stress
- The ability to maintain the integrity of the passivation layer

But, it is impossible to guarantee all this things. So, what do can we do? We can look at one of the main factors in most of the corrosion we see, and that is the level of chloride ions.

Chloride ions are present in many supply water sources, generally in low amounts (around 10 to 20 ppm), but they can be present up to 100 ppm or even higher. We can try to eliminate chlorides from our supply water using water treatment; however, care must be taken so as not to allow the buildup of chloride concentration over time. DI water, if well maintained, would be an option. RO water is also a good choice because it eliminates up to 98% of dissolved solids, including chlorides from the supply water. **But**, 2% can still pass through. Over time, concentrations can build up to levels that cause corrosive effects.

We need to prevent concentration build up, even with RO water, by using drain events on a frequency based on some level of tolerance that we are willing to accept. This is what we did, after reviewing several sources, when we came up with our supply water guidelines in Table 48-1 to help us determine an appropriate level based on water type. We looked at work from resources such as the Nickel Development Institute, Atlas Steel, Allegany Ludlum Corporation, the National Physical Laboratory, the *Water Purification Handbook*, and others, including competitive positions.


The end result is that we now have chloride concentration level supply water guidelines depending on water type for DI/RO water, softened water, and hard water (also known as tap or potable water) as shown in the table.

We do not want the average overall concentration in a humidifier tank to be more than 10 times these levels. It is now possible to determine cycles of concentration in the tank in order to determine the drain frequency needed to mitigate corrosion potential based on chloride concentrations in the supply water.

Table 48-1:
DriSteem supply water guidelines

Chlorides* RO or DI water Softened water Tap water * Damage caused by chloride corrosion is not covered by your DriSteem warranty.	< 5 ppm < 25 ppm < 50 ppm
Total hardness Tap water	< 500 ppm
pH RO, DI, or softened water Tap water	7 to 8 6.5 to 8.5
Silica	< 15 ppm
You may wish to take action to mitigate potential negative effects to your humidifier. Supply water outside of these guidelines may void your DriSteem warranty. Please contact your DriSteem Representative or DriSteem Technical Support if you need advice.	

Section VI: Terminology



ALKALINITY

The capacity water has to neutralize an acid.

Made up from ionic species such as CO_3^{2-} (carbonate), HCO_3^- (bicarbonate), and OH^- .

These accept (or give off) H^+ ions, stabilizing the pH of the water solution when acidic or basic chemicals (buffers) are added.

These ions are the substances that account for the formation of scale with calcium and magnesium.

ATOM

The basic unit of matter

The term “atom” is derived from the Greek “atomos” which was meant to describe the smallest indivisible particle for any given substance. Obviously, we have since learned how to split the atom with a process called nuclear fission.

An atom is made up of a dense, central nucleus which contains protons (positively charged) and neutrons (neutral) and surrounded by a “cloud” of electrons (negatively charged).

Note: The nucleus of a hydrogen atom contains one proton and no neutrons.

A neutral (uncharged) atom has the same number of protons as electrons.

ATOMIC WEIGHT

Every individual atom has a specific weight that corresponds to the number of protons and neutrons that make up that atom. Electrons have very little weight and contribute essentially nothing to the atomic weight. The atomic weight for any atom can be found on the Periodic Table of the Elements. For example, calcium has an atomic weight of 40. There are 20 protons and 20 neutrons in the nucleus of a calcium atom. So, the atomic weight for calcium is 40.

ANION

Negatively charged ion. The number of electrons is greater than the number of protons.

CATION

Positively charged ion. The number of protons is greater than the number of electrons.

COVALENT BOND

Unlike ionic bonds where the participants are anions and cations and have a full charge, (the anions take on electrons giving them negative charges and the cations give up electrons giving them positive charges).

Covalent bonds exist by sharing two electrons between two atoms. Neither atom has a full positive or negative charge. However, electrons making up a covalent bond may or may not spend more time nearer to one atom than the other. If they do, it will result in partial negative and partial positive characteristics making that bond polar, like a magnet. This is the case in a water molecule where there are two covalent bonds between hydrogen and oxygen atoms.

HARDNESS

Technically, the sum of all polyvalent cations (positive ions).

Practically, the sum of Ca^{+2} and Mg^{+2} ions (these are usually the predominant constituents). Ca^{+2} typically accounts for 70 – 90%.

Typically reported as CaCO_3 equivalents using equivalent weights of each species.

Expressed as mg/l or ppm, grains (ppm/17.1), French degrees (ppm/10), German degrees (ppm/17.8), Clark degrees (ppm/14.3)

ION

A charged atom, or atom in which the total number of protons and electrons are not equal.

IONIC BOND

The strong electrostatic force that holds positive and negative ions together in a lattice structure.


Positives and negatives attract each other. In chemistry this attraction occurs between positive and negative ions that are held together by this electrostatic force. When several of the same positive and negative ions come together, they form a lattice structure that is held together by this electrostatic force.

IONIC COMPOUND

A chemical compound in which positive and negative ions are held together in a lattice structure by ionic bonds.

The lattice structure is made up of positively charged ions and negatively charged ions.

Sodium chloride (table salt), shown in Figure 51-1, is an ionic compound. The sodium ions have a positive charge and the chloride ions have a negative charge.

FIGURE 51-1: SODIUM CHLORIDE

MOLE

Term similar to a dozen except that the number of things in a dozen is 12, and the number of things in a mole is 6.023×10^{23} . Avagadro figured out that this is the number of atoms (or molecules) in the atomic (molecular) weight of that substance expressed in grams. For example, the molecular weight of water is 18 so, a mole of water molecules has a weight of 18 grams (18 g/mole).

MOLECULE

At least two atoms held together by covalent bonds. Molecules are neutral because they do not have a net charge like ions. Water (H_2O) is a molecule.

MOLECULAR WEIGHT

Molecular weight is determined by adding the atomic weights of each element in a molecule. The atomic weight for hydrogen is 1 (its nucleus contains only 1 proton), and oxygen's atomic weight is 16 (its nucleus contains 8 protons and 8 neutrons for a total of 16). So, H_2O has a molecular weight of 18.

PH

pH is a measure of the acid or base levels of the water.

H^+ is acidic and OH^- is basic.

The pH range is 0 to 14. The number is technically the negative $\log_{10}$ of the H^+ ion concentration.

7 is neutral (hydrogen ions and hydroxyl ions are equal).

> 7 is basic (hydroxyl ions are greater than hydrogen ions).

< 7 is acidic (hydrogen ions are greater than the hydroxyl ions).

POLYVALENT ION

An ion that has a charge greater than one.

TOTAL DISSOLVED SOLIDS (TDS)

All substances that are dissolved in the water.

Principal TDS contributors: calcium and magnesium carbonates and bicarbonates (principal scale forming substances) among others.

Notes

Steve Felber was in the HVAC business for more than 30 years. He was a product manager for Honeywell's indoor air quality business for the first half of his career and a DriSteem Product Manager for the second half.

DriSteem relied on Steve's humidification and water chemistry expertise until his retirement in 2017.

Steve and his wife, Debbie, live in Eagan, Minnesota.



